
VERIFING W783 USING MASTER GAGE W343



TO VERIFY W783 USING W343

- 1. LOCK W783 AT 53 INCHES
- 2. MOUNT W783 WITH MEASURING END POINTING TOWARD GAGE PIN
- 3. SQUARELY CONTACT REAR OF W783 AGAINST REAR GAGE BLOCK
- 4. MOVE GAGE PIN TO CONTACT MEASURING NOSE OF W783
- 5. PIN SURFACE "A" MUST BE FLUSH OR INSIDE FRONT BLOCK AND
- 6. PIN SURFACE "C" MUST BE FLUSH OR OUTSIDE FRONT BLOCK

SURFACE "A" FLUSH WITH SURFACE MEASURES 53.015 INCHES

SURFACE "B" FLUSH WITH SURFACE MEASURE 53.000 INCHES

SURFACE "C" FLUSH WITH SURFACE MEASURES 52.985

